

## INSTALLATION DIRECTIONS / ROUGH-IN OPENING FOR SHUTTER FANS

1. Cut rough-in opening in wall for appropriate size shutter fan - using chart below
2. Place fan in opening
3. Drill holes through the frame face at desired locations.
4. Fasten fan in opening using appropriate fasteners. (not furnished)

MODEL #	FAN SIZE	ROUGH-IN SIZE
SF1276-1	12"	12 5/8" X 12 5/8"
SF1612-1	16"	16 5/8" X 16 5/8"
SF2030-1	20"	20 5/8" X 20 5/8"

Note: all shutter fans are variable speed. Variable speed controls and mechanical thermostats are available for these shutter fans as an option.

